

Dräger Liquid Extraction method Dräger-Tubes

Easy, fast and cost-effective: The Dräger Liquid Extraction method (DLE) is a field method used to analyze highly volatile harmful substances in water and other liquids.



ST-1354-2004

Benefits

Proven measurement system

The air extraction method is a proven and reliable system designed for the rapid analysis of water, waste water, oil sludge, soil and multi-phase samples using Dräger-Tubes. The method is based on the extraction of a contaminant from the liquid phase into the gas phase.

Fast and reliable in use

Using the DLE set, exceeding limit values and out-of-limit conditions are recognized within the shortest possible time so that environmental protection measures and precautions can be taken or malfunctions as of technical facilities can be identified and fixed.

On-site measurement

Low cost and rapid results mean a highly flexible method of measuring. Therefore, the Liquid Extraction method is particularly suitable for frequent on-site measurements.

System components



D-19328-2009

Dräger-Tube pump accuro

Fast measurement with one hand: The Dräger-Tube pump accuro allows you to use the established Dräger-Tubes to take measurements under extreme conditions. The easy-to-use Dräger-Tubes have already been calibrated and form a perfect unit with the Dräger-Tube pump.

Related Products

ST-14162-2008



Dräger CMS

The world's only Chip Measurement System (CMS) makes spot measurements as easy as 1, 2, 3: insert chip – start measurement – read measurement result on the LCD display. The Dräger CMS combines the advantages of the Dräger-Tubes with those of an optoelectronic analysis system.

D-12091-2010



Dräger X-act® 5000

The automatic tube pump Dräger X-act® 5000 is the first all-in-one solution designed for measurements with Dräger short-term tubes and for sampling tubes and systems. Ease of operation and a high degree of reliability compliment the measurement and sampling of gases, vapors and aerosols.

Notes

CORPORATE HEADQUARTERS
Drägerwerk AG & Co. KGaA
Moislinger Allee 53–55
23558 Lübeck, Germany
www.draeger.com

**REGION EUROPE CENTRAL
AND EUROPE NORTH**
Dräger Safety AG & Co. KGaA
Revalstraße 1
23560 Lübeck, Germany
Tel +49 451 882 0
Fax +49 451 882 2080
info@draeger.com

REGION EUROPE SOUTH
Dräger Safety France SAS
25, rue Georges Besse
92182 Antony Cedex
Tel +33 1 46 11 56 00
Fax +33 1 40 96 97 20
europe.south@draeger.com

REGION MIDDLE EAST, AFRICA
Dräger Safety AG & Co. KGaA
Branch Office
P.O. Box 505108
Dubai, United Arab Emirates
Tel +971 4 4294 600
Fax +971 4 4294 699
contactuae@draeger.com

REGION ASIA PACIFIC
Dräger Safety Asia Pte Ltd
25 International Business Park
#04-20/21 German Centre
Singapore 609916
Tel +65 6308 9400
Fax +65 6308 9401
asia.pacific@draeger.com

**REGION CENTRAL
AND SOUTH AMERICA**
Dräger Panama S. de R.L.
Complejo Business Park,
V tower, 10th floor
Panama City
Tel +507 377 9100
Fax +507 377 9130
contactcsa@draeger.com

Locate your Regional
Sales Representative at:
www.draeger.com/contact

